

swift
PROMOTOR
360
PC TABLET
SECURE TOP

The successful Swift Promotor 360 PC tablet version is now available with a secure top option. Once the PC tablet is positioned in place and the outer top is added simply line up the top and secure it in place with the supplied fixings and handy to use durable screwdriver ensuring the top cannot be moved without unscrewing the fixings, keeping the PC tablet in place and secure when in use.

- Easy to use option.
- Fixings and screwdriver come with product.
- Spare fixings also included.
- Low cost option.
- Now a great way to secure your PC tablet using Swift Promotor 360.

This product was designed taking into account an iPad2 and Air, however many other PC tablet devices can be used with this product as well.



• Inner top placed in position



• Line up inner cap hole with graphic wall clip



• Graphic put in place



• Raised locator to ensure correct positioning of device



• Outer top fits over top of graphic and PC tablet



- Use provided secure screws and screwdriver to fix item tightly in place, both sides secured
- Spare secure screw, and secure clip provided with product along with screwdriver

