

Parasol Assembly Instructions




IMPORTANT, PLEASE READ CAREFULLY AND KEEP
FOR FUTURE REFERENCE

Thank you for purchasing one of our high quality Hoyland Fox design parasols.

For safety reasons and to optimise the life of your parasol we recommend that you:

- Do not let children play with this product
- Keep away from flames and direct sources of heat, such as patio heaters and barbecues
- Do not suspend anything with any weight from the ribs, frame or canopy
- Ensure that all product components and fixtures are secure.
- Do not use if you have any doubts about the suitability for its intended use

Caution: The product is designed for use during fine weather and light winds. The safety and durability of the product cannot be guaranteed if used in windy/harsh weather conditions.



IMPORTANT:

- Only raise canopy with pole in vertical position. Attempting to open the canopy whilst holding the parasol horizontal compromises the smooth opening function and if forced could damage the frame.
- If optional base 'D' has been purchased always ensure it is filled with water - or sand if additional weight is required.

Note: Top cap 'C' will already be fitted if purchased with a canopy.